



Optical alignment device BFI 235-Ex for Ex-housing

For alignment of the visual axis of the Flame Scanner / Compact Flame Controller.

The circle insight the visor represents the detecting area of the sensor.

With a swivel mount the visual axis can be aligned as shown below. The images in the upper line show a correct alignment.

The images in the lower line show a misalignment of the visual axis of the flame scanner or a negative influence by burner internals.



Remove the cover incl. Flame Scanner electronic, replace it with the optical alignment device and fix it with the screws.

NOTICE

Housing to be opened by ex-qualified personnel only when it is deenergized!

Weight	approx. 1.0 kg
Material	aluminum, anodized black